

# PERMANENT BONDING – LONGLASTING SOLUTION

## STEP BY STEP: ADHESIVE

Due to permanent bonding, the attachment survives various life situations. The adhesive is modeled on the body and absorbs and releases moisture. Sports or swimming with a hair system is also possible. After the exposure time, the adhesive is ready for hotter temperatures. So a relaxing sauna or a longer holiday is possible without hesitation.

If you still have questions or if you are stuck at a step, you can reach us during our business hours at +49 2241 25527-17.



**1.**

**Tip**  
Moisture and heavy loads during the first 24 hours reduce liability.

**Use products**

**AD3 TAPE STRIP**  
749362  
Durability: In perfect conditions up to 2 weeks

---

**oder**

**GEOBOND TAPE STRIP**  
729343  
Durability: In perfect conditions up to 4 weeks

**Additional materials required:**

### Steps 1-6

- 1.**  
Cut the adhesive strips, such as Geobond or AD3 adhesive strips, into 1.5 cm wide strips. The protective film remains on the adhesive strip. The individual adhesive strips also make it possible to glue a curve.
- 2.**  
The excess protective film is removed from the adhesive strip so that it can be placed.
- 3.**  
The cut adhesive strips are glued along the edge of the base. An overlap of the adhesive strips is absolutely necessary for a flat adhesive performance, especially with the curves. Folding up the protective film allows the adhesive strips to overlap.
- 4.**  
The protective film is removed from the adhesive strip so that it is activated.
- 5.**  
The hair system is attached to the vertebral area and rolled off with slight pressure and tension to the side over the head arch up to the forehead. Depending on the hair situation, rolling from the forehead to the spinal area is also possible.
- 6.**  
The adhesive is activated by body heat. With the help of a towel and pressure, the glue heats up and the liability is activated.

**3.**

**4.**

**Tip**  
When the hairpiece begins with the hairline, rolling from the front to the back is recommended in order to create an optimal edge.

**5.**

**Tip**  
Excess water after showering or swimming must be removed from the adhesive by briefly applying strong pressure with a towel.

**6.**